

Navigating JSDiag

JSDiag has several different views. You can switch between views one of three ways: clicking the toolbar icons, pressing the hot key, or using the menu. Each view will be described in detail in the remaining sections of this manual.

Table 1. Toolbar Buttons

Button	Function	Hot Key
	Parameter Editor	F2
	Image View	F3
	Laser Image View	F4
	Laser View	F5
	Graph View	F6
	Pause/Restart	P
	Calibration Editor	F7
	Previous Scanner	Page Up
	Next Scanner	Page Down